## //ORIGINAL WINDMASTER® SIGN STANDS//



4814HDK For use with MDI DuraLatch signs, 2-pocket signs and MDI Compact signs. Dual spring. Telescoping legs.



**3612DLK** For use with MDI DuraLatch signs, 2-pocket signs and MDI Compact signs. Dual spring. Telescoping legs.

## DROP-N-LOCK UPRIGHT

The molded cap helps to channel your MDI crossbrace into the upright. The spring-loaded pin automatically locks your MDI DuraLatch<sup>®</sup>, MDI Compact<sup>®</sup> or 2-pocket sign in place.



## CAMLOCK<sup>®</sup> UNIVERSAL SIGN BRACKET

Slide the vertical crossbrace on the sign into the channel of the CamLock bracket and pull up on the handle. This will tighten the pressure plate against the crossbrace and lock it securely into place.



## SCREW-LOCK UNIVERSAL SIGN BRACKET

Slide the vertical crossbrace on the sign into the bracket channel. Secure sign by turning the screw handle until crossbrace fits tightly against pressure plate.



Model	Deployed	Sign	Folded Dimensions	Weight	Roll-Up Signs		Rigid	WindMaster
Number	Height*	Height**	(HxWxD)		MDI Compact®	MDI DuraLatch®	Signs	Springs
3612®DLK	80"	14"	25" X 6½" X 6½"	17 lbs.		<b>•</b>		Dual
4814M®-DLK	82"	14"	25" X 6½" X 6½"	22 lbs.	—	<b>•</b>	—	Dual
4814CAM	82"	14"	33" X 6½" X 6½"	25 lbs.	—	<b></b>	—	Dual
4814M-SL	82"	14"	25" X 6½" X 6½"	25 lbs.	_	<b></b>	—	Dual
4814HDK	82"	14"	30" X 6½" X 6½"	22 lbs	—	<b></b>	—	Dual

\* To top of 48" sign without flags

\*\* Distance from bottom of 48" sign to ground